

PHEMTO: MEGAlib Simulations

José Sousa

12-11-2025

Overall Assumptions: detectors

CZT/CdTe Detectors performance:

density = 5.79 g/cm³

threshold = 4 keV

noise = 0.5 keV

dx dy = 0.25mm

Energy resolution:

```
CZTcal5mm_U.EnergyResolution Gauss    40    40    1.8    // values borrowed from Alex
CZTcal5mm_U.EnergyResolution Gauss   100   100    2
CZTcal5mm_U.EnergyResolution Gauss   500   500   2.5
CZTcal5mm_U.EnergyResolution Gauss  1000  1000    5
CZTcal5mm_U.EnergyResolution Gauss  2000  2000   10
CZTcal5mm_U.EnergyResolution Gauss  5000  5000  25
```


Overall Assumptions: sources

Example Source:

- Laue Lenses
- 1.5mm diameter focus [1,2]
- monochromatic 104keV

This simulations only for energies where laue lenses operates, [50, 700]keV

For $E < 50\text{keV}$, used detector eff data on Laurent excel




CONFIG 1

Si (green):
6.65x6.65cm², 450μm thick

CdTe (blue):
6.4x6.4cm², 2mm thick

5cm spacing




CONFIG 1

Simulated efficiency
for Energies:

```
E_init = 50
Log_E=[]
while E_init <= 693.5:
    Log_E.append(E_init)
    E_init = E_init + 6.5
```

To be compliant with
Laurent Excel



CONFIG 1


Sensitivity Comparison:

- Red, Laurent det eff

Assumption (used 6.06 CdTe ro)

- Black, MEGAlib


simulated eff from 50kev to 700kev



CONFIG 1

Effective Area using:


- Area lenses from Laurent excel
- multiply det_Eff x area





CONFIG 1

Sensitivity using:

- simulated det effs (Si + CdTe)
- used Laurent excel for lenses eff








CONFIG 2

Si (green):
6.65x6.65cm², 450um thick

CdTe (red):
6.4x6.4cm², 5mm thick

5cm spacing




CONFIG 2

Simulated efficiency
for Energies:

```
E_init = 50
Log_E=[]
while E_init <= 693.5:
    Log_E.append(E_init)
    E_init = E_init + 6.5
```

To be compliant with
Laurent Excel



CONFIG 2


Sensitivity Comparison:

- Red, Laurent det eff

Assumption (used 6.06 CdTe ro)

- Black, MEGAlib


simulated eff from 50kev to 700kev



CONFIG 2

Effective Area using:


- Area lenses from Laurent excel
- multiply det_Eff x area




CONFIG 2

Sensitivity using:

- simulated det effs (Si + CdTe)
- used Laurent excel for lenses eff






CONFIG 3

Si (green):
6.65x6.65cm², 450μm thick

CdTe (red):
6.4x6.4cm², 10mm thick

5cm spacing




CONFIG 3

Simulated efficiency
for Energies:

```
E_init = 50
Log_E=[]
while E_init <= 693.5:
    Log_E.append(E_init)
    E_init = E_init + 6.5
```

To be compliant with
Laurent Excel



CONFIG 3


Sensitivity Comparison:

- Red, Laurent det eff

Assumption (used 6.06 CdTe ro)

- Black, MEGAlib


simulated eff from 50kev to 700kev



CONFIG 3

Effective Area using:


- Area lenses from Laurent excel
- multiply det_Eff x area




CONFIG 3

Sensitivity using:


- simulated det effs (Si + CdTe)
- used Laurent excel for lenses eff






Comparison between configs

Sensitivity



Effective Area



Future Work

Detectors:

- get more realistic CZT and CdTe energy resolution (simulations from Jose or use MC2 values from Hugo Allaire/Alline)
- get more realistic Si energy resolution (see newAthena WFI instrument)

Alternative Configurations:

- check how the PSF of Laue/mirror is on side detector of config4 and config5 (see last slide for figure of config4 and config5)

New Instrument Geometry:

- Add Pb (0.13 cm thick) collimator
- Add anti-coincidence detector (for particle rejection, in case particles are simulated on the background model)
- Understand the impact of the Collimator on config4 and config5

Sources:

- get x-ray optics point spread functions (can be an approximation)
- update Laue source for collimated source with double Gaussian.
- use [5] for background simulations

Future Work

Polarimetry:

- analysis for inter-plane compton (high energy polarimetry)
- analysis for on side CZT plane polarimetry (config4, config5), 20keV goal (low energy polarimetry)

References


- [1] Ferrari, E., Ferrari, C., Virgilli, E., Caroli, E., Auricchio, N., Stephen, J. B., Ferro, L., da Silva, R. C., and Moita, M. (2025). Correction: Imaging performance of laue lenses made of ge and si bent crystals for future gamma-ray astrophysics telescopes. Aerotecnica Missili amp; Spazio.
- [2] Frontera, F. (2025). Hard x-ray/soft gamma-ray laue lenses for high energy astrophysics.
- [3] Lucchetta, G. et. al. (2022). Introducing the MeVCube concept: a CubeSat for MeV observations. [doi:10.1088/1475-7516/2022/08/013](https://doi.org/10.1088/1475-7516/2022/08/013)
- [4] <https://doi.org/10.48550/arXiv.2108.02860>
- [5] Cumani, P., Hernanz, M., Kiener, J. et al. Background for a gamma-ray satellite on a low-Earth orbit. Exp Astron 47, 273–302 (2019). <https://doi.org/10.1007/s10686-019-09624-0>

Extra Configs

(moving optics to focus on Red detector)

Config4:

green Si
Blue 2mm CdTe
Red 5mm CZT



Config5:

green Si
Blue 2mm CdTe
Red 10mm CZT

